

## Applies to HE, HE+, SE, and Sensei Models

1

## Primary Pump:

Pump must be sized for the flow rate of the heating system. Pump must also be sized to overcome pressure loss through the system at the desired flow rate. Refer to the IO Manual for the model's pressure loss curve. Pump to be of bronze or stainless construction.

Gas Supply	,								
									С
	7								
Primary	•								
Pump									-
<u>/</u>									
ir Handle									В
	NAME	DATE			•		•		_
DRAWN	AB	11.16.2018			III	П	<b>a</b> 1	Ø	_
CHECKED	SH	12.15.2018	TITLE:		me Do	sian	Mani	ادر	
ENG APPR.	RS 12.15.2018		Systems Design Manual Rinnai Tankless						A
COMMENTS			Generic						
			SIZE	DWG.	NO.			REV	-
			В		WH1-A	λH			
			SCAL	E: NTS	WEIGHT:		SHEET	Г 1 OF 1	
		2					1		_

D